

Care Instructions

Eos Platform Lounger – designed by Matthew Hilton

To prolong the life of the product and retain its appearance and functionality, we would like to give you some relevant information and care advice:-

Made from aluminium with a Textilene sling, the Eos outdoor range is durable, light-weight, rustproof and low maintenance. Regular periodic care and cleaning is recommended over occasional heavy duty maintenance

The frame is finished in a hardwearing powdercoat which can be cleaned using a sponge / soft bristle brush with a cleaning solution of mild liquid soap and lukewarm water. The use of abrasive cleaners should be avoided.

Rinse and dry thoroughly for best finish.

Caution: In seaside use, salt can accumulate on the finish which may lead to surface damage

In indoor pool areas, chlorides can accumulate on the finish which may lead to surface damage.


In both of these environments, repeated cycles of condensation followed by evaporation will cause build-up of these aggressive corrosives. Regular cleaning with mild soap and water will remove the concentrated deposits and protect the furniture finish per the above instructions.

Although the materials and finishes used are selected for their 'all weather / year-round' characteristics, we recommend that the product is stored during cold and wet winter months. The lounger should not be stored upside down.

We thank you for purchasing this product and wish you many years of enjoyable and functional use.

For more related products please visit: casefurniture.com

Eos Platform Lounger



case


Case Furniture Ltd
London, SW18 2HZ
United Kingdom
info@casefurniture.com
casefurniture.com

case

Instructions


Right hand to left hand platform adjustment

1




Two people should turn the lounge onto its side on a soft flat surface. Remove the back sling and back adjustment plate.

2



With the frame on its back, remove and rotate the seat sling 180 degrees.

3




Re-attach the seat sling at the opposite end of the frame.

4


Re-bolt the back adjustment plates into the same position on the opposite side using bolts A.

Towards centre of frame



5

Place the lounge back onto its side. Insert the back adjustment bars into the plates by tilting the backrest slightly and re-attach the two bolts B into the correct holes




Provided



A x4



B x10



C x12

Required



D (5mm)